

## 12 Intermediate service kit

Ref	Part No	Description	Machine unit number or Subassembly description							Notes
			546669-							
			-09	Quantity						
1	223406 29	O-ring	1							Support/ Connecting housing
2	545800 01	Rectangular ring	1							Distributing ring upper
3	545800 02	Rectangular ring	1							Distributing ring lower
4	545800 03	Rectangular ring	1							Operating slide
5	543446 02	Rectangular ring	1							Sliding bowl bottom/ Bowl body
6	223404 20	O-ring	1							Inlet pipe/ Connecting housing
7	223404 10	O-ring	1							Inlet pipe/ Safety device
8	223406 14	O-ring	2							Leader cone/ Top disc
9	260104 91	O-ring	2							Distributing ring upper
10	73632	O-ring	1							Distributing ring upper
11	223404 82	O-ring	2							Cap nut
12	68011	O-ring	1							Distributing ring lower
13	223406 35	O-ring	1							Distributing ring lower
14	223406 22	O-ring	1							Bowl hood/ Paring disc chamber
15	74067	O-ring	1							Paring disc/ Support
16	545871 01	Valve plug	3							Operating slide
17	541691 01	Seal ring	1							Bowl hood
18	223404 22	O-ring	1							Inlet pipe/ Connecting housing
19	537086 03	Molybdenum disulfide past	1							
20	539474 03	Silicone grease	1							
99	573399	Exploded view	1							

